

E Fascia
Temporary
Installation Guidelines

1. Lay board out in order to mark where you will be drilling it



2. In the case where it will be a straight cut mark the board 1 1/2" from the edge as illustrated



3. If the cut is mitered (45 deg.) at a corner mark the board back 3" from the cut edge



4. Using a 3/8" drill bit drill a hole at each mark through the top wall of the product. **DO NOT DRILL THROUGH BOTTOM WALL**



5. Mark the board same as step 1 every 12" for the entire length of the board.



6. Position board against the rim joist and secure E Fascia using a 1 – ½" pan head screw through the drill hole securing the back wall of the E Fascia to the rim joist .



7. After securing all the E Fascia to the rim joist plug the holes using a 3/8" hole plug.

